

INTEGRATED TECHNICAL EDUCATION CLUSTER AT ALAMEERIA

E-626-A Real-Time Embedded Systems (RTES)

Lecture #3 PIC Microcontrollers

Instructor: Dr. Ahmad El-Banna)anna

Ahmad







What is a microcontroller?

- A microcontroller (sometimes abbreviated µC, uC or MCU) is a small computer on a single integrated circuit containing a processor core, memory, and programmable input/output peripherals.
- It can only perform simple/specific tasks.
- A microcontroller is often described as a 'computer-on-achip'.





Ahmad

Microcomputer system and Microcontroller based system







Figure 2: A microcontroller based system



4

Microcontrollers.

- Microcontrollers are purchased 'blank' and then programmed with a specific control program.
- Once programmed the microcontroller is build into a product to make the product more intelligent and easier to use.
- A designer will use a Microcontroller to:
 - Gather input from various sensors
 - Process this input into a set of actions •
 - Use the output mechanisms on the microcontroller to do something useful.







Types of Microcontrollers

- Parallax Propeller
- Freescale 68HC11 (8-bit)
- Intel 8051
- Silicon Laboratories Pipelined 8051 Microcontrollers
- **ARM** processors (from many vendors) using **ARM7** or Cortex-M3 cores are generally microcontrollers
- STMicroelectronics STM8 (8-bit), ST10 (16-bit) and STM32 (32-bit)
- Atmel AVR (8-bit), AVR32 (32-bit), and AT91SAM (32-bit)
- Freescale ColdFire (32-bit) and SO8 (8-bit)
- Hitachi H8, Hitachi SuperH (32-bit)
- Hyperstone E1/E2 (32-bit, First full integration of RISC and DSP on one processor core [1996])
- Infineon Microcontroller: 8, 16, 32 Bit microcontrollers for automotive and industrial applications.



Types of Microcontrollers..

- MIPS (32-bit PIC32)
- NEC V850 (32-bit)
- Microchip PIC (8-bit PIC16, PIC18, 16-bit dsPIC33/PIC24)
- PowerPC ISE
- **PSoC** (Programmable System-on-Chip)
- Rabbit 2000 (8-bit)
- Texas Instruments Microcontroller MSP 430 (16-bit), C2000 (32-bit), and Stellaris (32-bit)
- Toshiba TLCS-870 (8-bit/16-bit)
- Zilog eZ8 (16-bit), eZ80 (8-bit)
- etc

LO

Spring 201

Microcontroller Packaging and Appearance



From left to right: PIC 12F508, PIC 16F84A, PIC 16C72, Motorola 68HC05B16, PIC 16F877, Motorola 68000

Ahmad



8

S

PIC Microcontrollers

- Peripheral Interface Controller (PIC) was originally designed by General Instruments
- In the late 1970s, GI introduced PIC[®] 1650 and 1655 RISC with 30 instructions.
- PIC was sold to Microchip
- Features: low-cost, self-contained, 8-bit, Harvard structure, lacksquarepipelined, RISC, single accumulator, with fixed reset and interrupt vectors.



© Ahmad El-B

PIC Microcontroller product family

- 8-bit microcontrollers
 - PIC10
 - PIC12
 - PIC14
 - PIC16
 - PIC17
 - PIC18
- 16-bit microcontrollers
 - PIC24F
 - PIC24H

- 32-bit microcontrollers
 - PIC32
- 16-bit digital signal controllers
 - dsPIC30
 - dsPIC33F



S

Spring 201

 $\overline{\text{XTES}}$. Lec #3

PIC Microcontroller product family..

- The **F** in a name generally indicates the PICmicro uses flash memory and can be erased electronically.
- The C generally means it can only be erased by exposing the die to ultraviolet light (which is only possible if a windowed package style is used). An exception to this rule is the PIC16C84 which uses EEPROM and is therefore electrically erasable.

Microcontroller	Program memory	Data RAM	Max speed (MHz)	I/O ports	A/D converter
PIC17C42	2048 × 16	232	33	33	-
16C554	512 × 14	80	20	13	-
16C64	2048 × 14	128	20	33	-
16C71	1024 × 14	68	20	13	4
16F877	8192 × 14	368	20	33	8
16F84	1024 × 14	68	10	13	-

Table 1.3	Some PIC16CXXX and PIC16	FXXX family members
-----------	--------------------------	---------------------



S Spring 201 RTES, Lec#3



Why PIC16F877A is very popular?

- This is because PIC16F877A is very cheap. Apart from that it is also very easy to be assembled. Additional components that you need to make this IC work is just a 5V power supply adapter, a 20MHz crystal oscillator and 2 units of 22pF capacitors.
- What is the advantages of PIC16F877A?
- This IC can be reprogrammed and erased up to 10,000 times. Therefore it is very good for new product development phase.
- What is the disadvantages of PIC16F877A?
- This IC has no internal oscillator so you will need an external crystal of other clock source.



Key Features	PIC16F877	
MAX Operating Frequency	20MHz	
FLASH Program Memory (14-bit words)	8K	
Data Memory (bytes)	368	
EEPROM Data Memory (bytes)	256	
I/O Ports	RA0-5 (6) RB0-7 (8) RC0-7 (8) RD0-7 (8) RE0-2 (3)	
Timers	3	
сср (Capture/Compare/PWM)	2	
Serial Communications	MSSP, USART	
Parallel Communications	PSP	
10-bit Analog-to-Digital Module	8 Channels	
Instruction Set	35 Instructions	
Pins (DIP)	40 Pins	

Features

© Ahmad El-Banna

RTES, Lec#3, Spring 2015



© Ahmad El-Banna

RTES, Lec#3, Spring 2015



Bubble diagram of PIC16F877



Pin Diagram of PIC16F877

Quad Flat
 Package (QFP)





Plastic Leaded Chip Carrier
 Package (PLCC)



IJ

, Spring 201

RTES, Lec#3

Pin Diagram of PIC16F877..

 Plastic dual in-line package (DIP)







PIC16F877 Architecture



5 © Ahmad E l-Banna

RTES, Lec#3, Spring 201



18

PIC16F877 Internal Block Diagram

The basic architecture of PIC16F877 consists of Program memory, file registers and RAM, ALU and CPU registers.



Memory of the PIC16F877

- divided into 3 types of memories:
 - Program Memory A memory that contains the program (which we had written), after we've burned it. As a reminder, Program Counter executes commands stored in the program memory, one after the other.
 - 2. Data Memory This is RAM memory type, which contains a special registers like SFR (Special Function Register) and GPR (General Purpose Register). The variables that we store in the Data Memory during the program are deleted after we turn off the micro. These two memories have separated data buses, which makes the access to each one of them very easy.
 - Data EEPROM (Electrically Erasable Programmable Read-Only Memory) – A memory that allows storing the variables as a result of burning the written program.



Memory of the PIC16F877..

 Each one of them has a different role. Program Memory and Data Memory two memories that are needed to build a program, and Data EEPROM is used to save data after the microcontroller is turn off.



D

PIC16F877A Program Memory

- Is Flash Memory
- Used for storing compiled code (user's program)
- Program Memory capacity is 8K x 14 bit → Each location is 14 bits long
 - \rightarrow Every instruction is coded as a 14 bit word
- PC can address up to 8K addresses
- Addresses H'000' and H'004' are treated in a special way





Spring 201

RTES, Lec#3

PIC16F877A Data Memory (RAM)

- Memory storage for variables
- Data Memory is also known as Register File and consists of two components.
 - General purpose register file (same as RAM).
 - Special purpose register file (similar to SFR in 8051).
- Addresses range from 0 to 511 and partitioned into 4 banks
 → each bank extends up to 7Fh (128 bytes).
- The user can only access a RAM byte in a set of 4 banks and only one bank at a time. The default bank is BANKO.
- To access a register that is located in another bank, one should access it inside the program. There are special registers which can be accessed from any bank, such as STATUS register.

PIC16F877A Registers

- Some CPU Registers:
 - W
 - PC
 - FSR
 - IDF
 - PCL
 - PCLATH
 - STATUS





W Register

- W, the working register, is used by many instructions as the source of an operand. This is similar to accumulator in 8051.
- It may also serve as the destination for the result of the instruction execution. It is an 8-bit register.







S

Spring 201

Program Counter

- Program Counter (PC) is 13 bit and capable of addressing an 8K word x 14 bit program memory space.
- PC keeps track of the program execution by holding the address of the current instruction.
- It is automatically incremented to the next instruction during the ۲ current instruction execution.

Program Counter Stack

- an independent 8-level stack is used for the program counter. •
- As the PC is 13-bit, the stack is organized as 8x13bit registers.
- When an interrupt occurs, the PC is pushed onto the stack. When the interrupt is being served, other interrupts remain disabled. Hence, other 7 registers of the stack can be used for subroutine calls within an interrupt service routine or within the mainline program.



FSR & INDF

- FSR Register
- (File Selection Register, address = 04H, 84H)
 is an 8-bit register used as data memory address pointer. This is used in indirect addressing mode.

INDF Register

• (INDirect through FSR, address = 00H, 80H)

INDF is not a physical register. Accessing INDF is actually access the location pointed to by FSR in indirect addressing mode.



26

PCL & PCLATH

PCL Register

(Program Counter Low Byte, address =02H, 82H)
 PCL is actually the lower 8-bits of the 13-bit Program Counter. This is a both readable and writable register.

PCLATH Register

• (Program Counter LATCH, address = 0AH, 8AH)

PCLATH is a 8-bit register which can be used to decide the upper 5-bits of the PC. PCLATH is not the upper 5bits of the PC. PCLATH can be read from or written to without affecting the PC. The upper 3 bits of PCLATH remain zero and they serve no purpose. When PCL is written to, the lower 5bits of PCLATH are automatically loaded to the upper 5bits of the PC.





, Spring 201 RTES, Lec#3



- In order to start programming and build automated system, • there is no need to study all the registers of the memory map, but only a few most important ones:
 - **STATUS register** changes/moves from/between the banks.
 - **PORT registers** assigns logic values ("0"/"1") to the ports
 - **TRIS registers** data direction register (input/output)



STATUS Register

- Is an 8-bit register that stores the status of the processor.
- In most cases, this register is used to switch between the banks (Register Bank Select), but also has other capabilities.

R/W-0	R/W-0	R/W-0	R-1	R-1	R/W-x	R/W-x	R/W-x
IRP	RP1	RP0	TO	PD	Z	DC	С

- IRP Register Bank Select bit.
- **RP1:RP0: Register Bank Select bits.**
- **TO: Time-out bit**
- **PD: Power-down bit**
- Z: Zero bit
- DC: Digit carry/borrow bit
- C: Carry/borrow bit

Used in conjunction with PIC's sleep mode

Spring 201

Spring

, Lec#3

PIC16F877 Peripheral features

1. I/O Ports:

- PIC16F877 has **5 I/O ports**:
 - **PORT A** has 6 bit wide, Bidirectional
 - PORT B, C, D have 8 bit wide, Bidirectional
 - **PORT E** has 3 bit wide, Bidirectional
- In addition, they have the following alternate functions:

Port	Altenative us	No.of I/O pins	
Port A	A/D Convert	6	
Port B	External inte	8	
Port C	Serial port, T	8	
Port D	Parallel slave port		8
Port E	A/D Converter inputs		3
		Total I/O pins	33
		Total pins	40



, Spring 201

RTES, Lec#3

PIC16F877 Peripheral features..

- Each port has **2 control registers**:
 - TRISx sets whether each pin is an input(1) or output(0)
 - **PORT**x sets their output bit levels or contain their input bit levels.
- Pin functionality "overloaded" with other features.
- Most pins have 25mA source/sink thus it can drive LEDs directly.



LO.

Spring 201

PIC16F877 Peripheral features...

2. Analog to Digital Converter (ADC)

- Only available in 14bit and 16bit cores
- Fs (sample rate) < 54KHz
- The result is a 10 bit digital number
- Can generate an interrupt when ADC conversion is done
- The A/D module has 4 registers:
 - A/D Result High Register (ADRESH)
 - A/D Result Low Register (ADRESL)
 - A/D Control Register0 (ADCON0)
 - A/D Control Register1 (ADCON1)
- Multiplexed 8 channel inputs
 - Must wait T acq to change up sampling capacitor.
- Can take a reference voltage different from that of the controller.



RTES, Lec#3, Spring 2015



3. Timer/counter modules

- Generate interrupts on timer overflow
- Can use external pins as clock in/ clock out (ie. for counting events or using a different Fosc)
- There are **3 Timer/counter modules**:
 - Timer0: 8-bit timer/counter with 8-bit pre-scaler
 - Timer1: 16-bit timer/counter with 8-bit pre-scaler, can be incremented during SLEEP via external crystal/clock
 - Timer2: 8-bit timer/counter with 8-bit period register, pre-scaler and post-scaler.



PIC16F877 Peripheral features.....

- 4. Universal Synchronous Asynchronous Receiver Transmitter (USART/SCI) with 9-bit address detection.
 - Asynchronous communication: UART (RS 232 serial)
 - Can do 300bps 115kbps
 - 8 or 9 bits, parity, start and stop bits, etc.
 - Outputs 5V \rightarrow needs a RS232 level converter (e.g. MAX232)
 - Synchronous communication: i.e with clock signal
 - SPI = Serial Peripheral Interface
 - 3 wire: Data in, Data out, Clock
 - Master/Slave (can have multiple masters)
 - Very high speed (1.6Mbps)
 - Full speed simultaneous send and receive (Full duplex)
 - I2C = Inter IC
 - 2 wire: Data and Clock
 - Master/Slave (Single master only)
 - Lots of cheap I2C chips available; typically < 100kbps



Spring 201

TES. Lec#3

PIC16F877 Peripheral features....

5. Capture, Compare, PWM modules

- Capture is 16-bit, max. resolution is 12.5 ns
- Compare is 16-bit, max. resolution is 200 ns
- PWM max. resolution is 10-bit

6. Parallel Slave Port (PSP) 8-bits wide, with external RD, WR and CS controls



S

Clock and Instruction Cycles

- Clock from the oscillator enters a microcontroller via OSC1 pin where internal circuit of a microcontroller divides the clock into four even clocks Q1, Q2, Q3 and Q4 which do not overlap.
- These four clocks make up one **instruction cycle** (also called machine cycle) during which one instruction is executed.





Clock and Instruction Cycles.

- Execution of instruction starts by calling an instruction that is next in string.
- Instruction is called from program memory on every Q1 and is written in Instruction Register (IR) on Q4.
- Decoding and execution of instruction are done between the next Q1 and Q4 cycles. The following diagram shows the relationship between instruction cycle and clock of the oscillator (OSC1) as well as that of internal clocks Q1 – Q4.
- Program Counter (PC) holds information about the address of the next instruction.



S

S

, Spring 201

RTES, Lec#3

38

Pipelining in PIC

- There are 35 single word instructions. A two-stage pipeline overlaps fetch and execution of instructions. As a result, all instructions execute in a single cycle except for program branches. These take two cycles since the fetch instruction is "flushed" from the pipeline while the new instruction is being fetched and then executed.
- A typical picture of the pipeline is shown in Figure 3.



Figure3: Instruction Pipeline Flow

D

Spring 201

RTES, Lec#3

39

- For more details, refer to:
 - Chapter 14, John Catsoulis, Designing Embedded Hardware, 2005.
- The lecture is available online at:
 - http://bu.edu.eg/staff/ahmad.elbanna-courses/12134
- For inquires, send to:

• <u>ahmad.elbanna@feng.bu.edu.eg</u>