

ECE 321

Electronic Circuits


Lec. 7: General Frequency Considerations

Instructor

Dr. Maher Abdelrasoul

<http://www.bu.edu.eg/staff/mahersalem3>

Agenda



Introduction

Introduction

- The analysis thus far has been limited to a particular frequency.
- We will now investigate the frequency effects introduced by the larger capacitive elements of the network at low frequencies and the smaller capacitive elements of the active device at high frequencies.
- Because the analysis will extend through a wide frequency range, the logarithmic scale will be defined and used throughout the analysis.
- In addition, because industry typically uses a decibel scale on its frequency plots, the concept of the decibel is introduced.

Logarithms and Decibels

Logarithms

- We use it to cover a wide range.

$$a = b^x, \quad x = \log_b a$$

Common logarithm: $x = \log_{10} a$

Natural logarithm: $y = \log_e a$

the logarithm of a number taken to a power is simply the power of the number if the number matches the base of the logarithm

<hr/> <hr/>	
$\log_{10} 10^0$	= 0
$\log_{10} 10$	= 1
$\log_{10} 100$	= 2
$\log_{10} 1,000$	= 3
$\log_{10} 10,000$	= 4
$\log_{10} 100,000$	= 5
$\log_{10} 1,000,000$	= 6
$\log_{10} 10,000,000$	= 7
$\log_{10} 100,000,000$	= 8
etc.	

$$\log_e a = 2.3 \log_{10} a$$




$$\log_{10} 1 = 0$$

$$\log_{10} \frac{a}{b} = \log_{10} a - \log_{10} b$$

$$\log_{10} \frac{1}{b} = -\log_{10} b$$

$$\log_{10} ab = \log_{10} a + \log_{10} b$$

Semi-log graph paper



$$\text{Value} = 10^x \times 10^{d_1/d_2}$$

Decibels

- **Power Levels**

$$G = \log_{10} \frac{P_2}{P_1}$$
 bel

$$G_{\text{dB}} = 10 \log_{10} \frac{P_2}{P_1}$$
 dB

$$G_{\text{dBm}} = 10 \log_{10} \frac{P_2}{1 \text{ mW}} \Big|_{600 \Omega}$$
 dBm

$$G_{\text{dB}} = 10 \log_{10} \frac{P_2}{P_1} = 10 \log_{10} \frac{V_2^2/R_i}{V_1^2/R_i} = 10 \log_{10} \left(\frac{V_2}{V_1} \right)^2$$

$$G_{\text{dB}} = 20 \log_{10} \frac{V_2}{V_1}$$
 dB

- **Cascaded Stages**

$$|A_{v_T}| = |A_{v_1}| \cdot |A_{v_2}| \cdot |A_{v_3}| \cdots |A_{v_n}|$$

$$G_{\text{dB}_T} = G_{\text{dB}_1} + G_{\text{dB}_2} + G_{\text{dB}_3} + \cdots + G_{\text{dB}_n}$$
 dB

- **Voltage Gains versus dB Levels**

Comparing $A_v = \frac{V_o}{V_i}$ to dB

Voltage Gain, V_o/V_i	dB Level
0.5	-6
0.707	-3
1	0
2	6
10	20
40	32
100	40
1000	60
10,000	80
etc.	

- Human Auditory Response !

Example

EXAMPLE 9.8 An amplifier rated at 40-W output is connected to a 10- Ω speaker.

- Calculate the input power required for full power output if the power gain is 25 dB.
- Calculate the input voltage for rated output if the amplifier voltage gain is 40 dB.

Solution:

a. Eq. (9.11): $25 = 10 \log_{10} \frac{40 \text{ W}}{P_i} \Rightarrow P_i = \frac{40 \text{ W}}{\text{antilog}(2.5)} = \frac{40 \text{ W}}{3.16 \times 10^2}$

$$= \frac{40 \text{ W}}{316} \cong \mathbf{126.5 \text{ mW}}$$

b. $G_v = 20 \log_{10} \frac{V_o}{V_i} \Rightarrow 40 = 20 \log_{10} \frac{V_o}{V_i}$

$$\frac{V_o}{V_i} = \text{antilog } 2 = 100$$

$$V_o = \sqrt{PR} = \sqrt{(40 \text{ W})(10 \text{ V})} = 20 \text{ V}$$

$$V_i = \frac{V_o}{100} = \frac{20 \text{ V}}{100} = 0.2 \text{ V} = \mathbf{200 \text{ mV}}$$

General Frequency Considerations

Low, High & Mid Frequency Range

Variation in $X_C = \frac{1}{2\pi f C}$ with frequency for a 1- μF capacitor

f	X_C
10 Hz	15.91 k Ω
100 Hz	1.59 k Ω
1 kHz	159 Ω
10 kHz	15.9 Ω
100 kHz	1.59 Ω
1 MHz	0.159 Ω
10 MHz	15.9 m Ω
100 MHz	1.59 m Ω

Variation in $X_C = \frac{1}{2\pi f C}$ with frequency for a 5 pF capacitor

f	X_C
10 Hz	3,183 M Ω
100 Hz	318.3 M Ω
1 kHz	31.83 M Ω
10 kHz	3.183 M Ω
100 kHz	318.3 k Ω
1 MHz	31.83 k Ω
10 MHz	3.183 k Ω
100 MHz	318.3 Ω

- The **larger capacitors** of a system will have an important impact on the response of a system in the **low-frequency range** and can be ignored for the high-frequency region.
- The **smaller capacitors** of a system will have an important impact on the response of a system in the **high-frequency range** and can be ignored for the low-frequency region.
- The effect of the capacitive elements in an amplifier are ignored for the **mid-frequency** range when important quantities such as the gain and impedance levels are determined.

Typical Frequency Response

$$P_{o_{mid}} = \frac{|V_o|^2}{R_o} = \frac{|A_{v_{mid}} V_i|^2}{R_o}$$

$$P_{o_{HPF}} = \frac{0.707 A_{v_{mid}} V_i|^2}{R_o} = 0.5 \frac{|A_{v_{mid}} V_i|^2}{R_o}$$

$$P_{o_{HPF}} = 0.5 P_{o_{mid}}$$

$$\text{bandwidth (BW)} = f_H - f_L$$

The band frequencies define a level where the gain or quantity of interest will be 70.7% of its maximum value.




FIG. 9.8

Gain versus frequency: (a) RC-coupled amplifiers; (b) transformer-coupled amplifiers; (c) direct-coupled amplifiers.

Normalization Process

- Normalized plot




FIG. 9.9

Normalized gain versus frequency plot.

- Decibel plot

$$\left. \frac{A_v}{A_{v\text{mid}}} \right|_{\text{dB}} = 20 \log_{10} \frac{A_v}{A_{v\text{mid}}}$$




FIG. 9.12

Decibel plot of the normalized gain versus frequency plot of Fig. 9.9.

Thank you!

