



**Benha University**

*Dr : Mohamed Ahmed Ebrahim*



Undergraduate Course

# *Electric Installation Design*

*Dr. Mohamed Ahmed Ebrahim*

E-mail: [mohamed.mohamed@feng.bu.edu.eg](mailto:mohamed.mohamed@feng.bu.edu.eg)

Web site: <http://bu.edu.eg/staff/mohamedmohamed033>



*Dr : Mohamed Ahmed Ebrahim*



# Lecture (3)




*Dr : Mohamed Ahmed Ebrahim*

## d) UPS

- Un-interrupted Power Supply is used to supply the critical loads that founded in hospitals, banks, or servers.
- The function of this device is to ensure uninterrupted the power for this important loads.
- The UPS operation is:
  1. Transferring AC to DC.
  2. Using the DC to charge the batteries.
  3. Transferring the output DC of the batteries to AC again.


# UPS Components



# UPS Types

## 1. Standby UPS


It is the most common type used for desktop computers.



Schematic diagram for Standby UPS

## 2. Line interactive UPS


It is the most common design used for small business, web, and departmental servers.



Schematic diagram for Line interactive UPS

### 3. Standby-ferro UPS

The standby-ferro UPS was once the dominant form of UPS in the 3-15 kVA range




Schematic diagram for Standby-ferro UPS



#### 4. Double conversion on-line UPS


This is the most common type of UPS above 10 kVA.



Schematic diagram for Double conversion on-line UPS

## 5. Delta conversion on-line UPS

It is a newer, 10 year old technology introduced to eliminate the drawbacks of the double conversion on-line design and is available in sizes ranging from 5 kVA to 1.6 MW.



Schematic diagram for Delta conversion on-line UPS

# UPS characteristics

	Practical power range (kVA)	Voltage conditioning	Cost per VA	Efficiency	Inverter always operating
Standby	0-0.5	Low	Low	Very High	No
Line interactive	0.5-5	Design Dependent	Medium	Very High	Design Dependent
Standby-ferro	3-15	High	High	Low - Medium	No
Double conversion on-line	5-5000	High	Medium	Low - Medium	Yes
Delta conversion on-line	5-5000	High	Medium	High	Yes

# UPS Nameplate

UNINTERRUPTIBLE POWER SUPPLY	
2033A SERIES	
TYPE	UP2033A-D5038U-2
SERIAL NO.	99-EFYW01-01
MODULE INPUT	3 $\phi$ , 3 WIRE, 208 VAC, 141.0 A, 60 Hz, 50.8 kVA, 0.8PF LAGGING
MODULE OUTPUT	3 $\phi$ , 4 WIRE, 208 VAC, 138.8 A, 60 Hz, 50 kVA, 0.8PF LAGGING
BYPASS INPUT	3 $\phi$ , 4 WIRE, 208 VAC, 138.8 A, 60 Hz, 50 kVA, 0.8PF LAGGING
BATTERY VOLTAGE	380 VDC, 120.8 A
VOLTAGE UNBALANCE	$\pm 1\%$ (100% LOAD UNBALANCE)
DATE	SEP, 1999
WEIGHT	885 kg ( 1470 LBS.)
 MITSUBISHI ELECTRIC CORPORATION	
A121711-801	
MADE IN JAPAN	

## e) Distribution Boards

- It is important element in electrical installation system, and its main function is to connect and disconnect the current, safety operation for any device, and over current protection.
- low voltage panels divided into two types:
  - ❖ Main panels.
  - ❖ Sub distribution panels.




## 2. Wiring and Raceways

Cables & Conductors

Wiring and Raceways

Bus Duct



Cable Trays



*Dr : Mohamed Ahmed Ebrahim*

# Cables Classification

Cables are classified based on multiple factors according to



# Cable selection factors

- ❖ Maximum operating voltage.
- ❖ Insulation level.
- ❖ Maximum load.
- ❖ Maximum overload and its duration.
- ❖ Maximum short circuit and its duration.
- ❖ Voltage drop.
- ❖ Cable length.
- ❖ Cable installation (under ground - on air - on pipes).
- ❖ Maximum temperature exposed to the cable.





# Cable Rating Information



## CABLE RATING TABLE

Cable Cross Sectional Area (mm <sup>2</sup> )	Typical Current Rating (amps)	Recommended Circuit Breaker Rating (amps)
1.5 mm <sup>2</sup>	7.9 - 15.9A	8A
2.5 mm <sup>2</sup>	15.9 - 22A	15A
4 mm <sup>2</sup>	22 - 30A	20A
6 mm <sup>2</sup>	30 - 39A	30A
10 mm <sup>2</sup>	39 - 54A	40A
16 mm <sup>2</sup>	54 - 72A	60A
25 mm <sup>2</sup>	71 - 93A	80A
50 mm <sup>2</sup>	117 - 147A	125A
70 mm <sup>2</sup>	147 - 180A	150A
95 mm <sup>2</sup>	180 - 216A	200A
120 mm <sup>2</sup>	216 - 250A	225A
150 mm <sup>2</sup>	250 - 287A	275A
185 mm <sup>2</sup>	287 - 334A	300A
240 mm <sup>2</sup>	334 - 400A	350A

# Ways to extend cables



# 3. Protective Devices

## Wiring and Raceways

**Circuit Breakers**

**Fuses**



*Dr : Mohamed Ahmed Ebrahim*

## a) **Circuit Breakers**

- A **circuit breaker** is an automatically operated electrical switch designed to protect an electrical circuit from damage caused by excess current, typically resulting from an overload or short circuit.
- Its basic function is to interrupt current flow after a fault is detected.
- A circuit breaker can be reset (either manually or automatically) to resume normal operation.

# Specifications of Circuit Breakers

- **The circuit breakers specification are determined by two values:**

- ❖ Rated current ( $I_{\text{rated}}$ ) “AMP”.

The maximum current passing in the circuit breaker without disconnect the CB.

- ❖ Short Circuit Capacity (SCC) “KA”.

The maximum current that the circuit breaker can withstand during the short circuit without burning.

# Types of Circuit Breakers



**Miniature circuit breaker  
(MCB)**



**molded case circuit breaker  
(MCCB)**



**ground fault circuit breaker  
(GFCB)**



# Differences between MCB & MCCB

	<b>MCB</b>	<b>MCCB</b>
<b>AMP</b>	less than 100 amps	high as 2,500 amps
<b>Interrupting rate</b>	interrupting rating is 18,000 amps	up to 200,000 amps
<b>Applications</b>	mostly installed for home use	generally utilized for commercial or industrial purposes
<b>Circuit breaker</b>	low-voltage circuit breakers created to meet IEC 947 standards	



# Circuit Breakers Rated Current Ratings

6, 10, 15, 16, 20, 25, 32, 40, 50, 63, 100,  
125, 150, 163, 200, 225, 250, 300, 400,  
500, 630, 800, 1000, 1200, 1500, 1750,  
2000, 2200, 2500, 3000, 3200, 4000, 5000, 6300  
(Amp)

## b) Fuses

- **Fuse** is an electrical safety device that operates to provide over current protection of an electrical circuit.
- A fuse is an automatic means of removing power from a faulty system; often abbreviated to Automatic Disconnection of Supply.
- Circuit breakers can be used as an alternative design solution to fuses, but have significantly different characteristics.
- There are two fuses types: cartridge fuses, and high rupturing capacity.

# Fuses Types

## Fuses Types

**Cartridge Fuses**



**High Rupturing Capacity**




# Differences between Cartridge Fuses & High Rupturing Capacity

	<b>Cartridge Fuses</b>	<b>High Rupturing Capacity</b>
<b>Function</b>	protect electrical appliances such as motors, air-conditions, refrigerator, pumps	used for short circuit protection in high voltage switchgear for 50 to 60 Hz frequency range
<b>Rating</b>	available up to 600A and 600V AC	2, 4, 6, 10, 16, 25, 30, 50, 63, 80, 100, 125, 160, 200, 250, 320, 400, 500, 630, 800, 1000, and 1250 amperes.
<b>Application</b>	used in industries, commercial as well as home distribution panels.	<ul style="list-style-type: none"><li>* Used in High Voltage motors up to 3 MW</li><li>* Capacitors up to 1200 kVAR</li><li>* Cable feeders.</li></ul>

*Dr : Mohamed Ahmed Ebrahim*

## 4. Control and Utilization Equipments



# *Electric Installation Design Regulations and Standards*



*Dr : Mohamed Ahmed Ebrahim*

# Regulations & Standards

## ❖ Regulations

In most countries electrical installation shall comply with more than one set of regulations, issued by national authorities or by recognized private bodies.

## ❖ Standards

Standards are used by a diverse range of organizations to enhance their products and services, improve safety and quality, meet industry best practice, and support trade into existing and new markets, (e.g. IEC, IEEE, and EC)

# Regulations & Standards History

- The implementation of standards in industry and commerce became highly important with the onset of the Industrial Revolution.
- Henry Maudslay developed the first industrially practical screw-cutting lathe in 1800, which allowed for the standardization of screw thread sizes for the first time.
- Maudslay's work, as well as the contributions of other engineers, accomplished a modest amount of industry standardization.
- Joseph Whitworth's screw thread measurements were adopted as the first national standard by companies around the country in 1841. It came to be known as the British Standard Whitworth, and was widely adopted in other countries.



- The Engineering Standards Committee was established in London in 1901 as the world's first national standards body.
- After the First World War, similar national bodies were established in other countries.
- The Detaches was set up in Germany in 1917, followed by its counterparts.
- The American National Standard Institute and the French Commission Permanente de Standardization, both in 1918.

# International Standards

## 1. International Electro technical Commission (IEC)

- **IEC** is the world's leading organization that prepares and publishes International Standards for all electrical, electronic and related technologies.
- **IEC** provides a platform to companies, industries and governments for meeting, discussing and developing the International Standards they require.



*Dr : Mohamed Ahmed Ebrahim*

## 2. Institute of Electrical and Electronics Engineers (IEEE)

- An organization that develops global standards in a broad range of industries.
- **IEEE** has developed standards for over a century, through a program that offers balance, openness, fair procedures, and consensus. Technical experts from all over the world.



*Dr : Mohamed Ahmed Ebrahim*

## Difference between Regulation & standard?

Regulations	Standards
A rule that we must follow	Not written by government but written by organizations.
Rules that the government makes under an act	Typically refer to product performance or how to do a job
Rules are made “real” and “enforceable” by the power that the government gives itself under an Act	Have no authority on their own, but may be adopted into regulations making them legal requirements
e.g. Health & Safety Act Regulation for Hearing Protection	May be referred to specifically in a regulation

# *Electrical Load Estimation*



*Dr : Mohamed Ahmed Ebrahim*

# What about Electrical Load Estimation

- **Electrical Load Estimation is very important in the draft design stage because it help to:**
  - ❖ Plan the connection to upstream network and MV circuit configurations.
  - ❖ Plan the transformers substation (if any).
  - ❖ Apply to Power Company for supply.
  - ❖ Calculate initial budget for the electrical works

# Electrical loads (non-industrial) classified to

- Lighting loads.
- Small Appliances loads.
- HVAC loads.
- fire fighting loads.
- low current loads.
- Dynamic loads (elevators - escalators).